



FIGURE 2

ARRANGEMENT
ISLAND PACKET 440






FIGURE 3



**ISLAND PACKET 440
DC PANEL SCHEMATIC**

FIGURE 4



**RED WIRE ARE POSITIVE
YELLOW WIRES ARE NEGATIVE**

☐ M OTHER CABIN LIGHTS
☐ F FOREPEAK LIGHT
☐ S LAZARETTE LIGHTS
☐ D DIMMER SWITCH
☒ FAN DROPSPEAKER DOWN

- (H) HEADLINER LIGHTS-WIRES ARE ROUTED BETWEEN DECK AND HEADLINER AND EXIT AT AFT STARBOARD LAZARETTE
- (L) CABIN SIDE LIGHTS
- (C) COURTESY LIGHT
- (B) BILGE LIGHT
- (E) ENGINE COMPARTMENT LIGHTS
- (R) REFRIGERATOR/FREEZER LIGHTS

DC WIRING DIAGRAM ISLAND PACKET 440

FIGURE 5





FIGURE 6



NOTE: NOT ALL CIRCUITS SHOWN


ISLAND PACKET 440 DC CHARGING SYSTEM

REVISION 1/4/07: DELETE OIL PRESSURE SWITCH

AND RUN BROWN POWER WIRE DIRECTLY TO PANEL

REVISION 3/5/07: CHARGE GENSET BATTERY THROUGH DUO CHARGE
HULLS #34 AND UP

FIGURE 6



AC PANEL SCHEMATIC ISLAND PACKET 440

THIS DIAGRAM IS FOR 120 VOLT AC SINGLE PHASE, 60 HZ,
30 AMP SHOREPOWER SERVICE

FIGURE 7

AC WIRING DIAGRAM ISLAND PACKET 440




FIGURE 8

SEE AC PANEL SCHEMATIC
FOR PANEL WIRING

WIRE ROUTES REPRESENT 16 AMP 3 WIRE FROM OUTLETS
UNLESS OTHERWISE NOTED

BLACK = HOT TO PANEL
WHITE = NEUTRAL TO NEUTRAL BUS
GREEN = GROUNDING TO GROUNDING BUS

THIS BOAT IS WIRED FOR 120 VOLT AC, SINGLE PHASE
60 HZ 30 AMP SHOREPOWER SERVICE

SHORE INLET
INLET BREAKER
INLET BREAKER
SHORE INLET
BATTERY CHARGER
MICROWAVE OVEN
AC BIR LIPS
AC PANELS
STOVE
SINK

WHERE ROUTES REPRESENT 10 AND 3 WIRE FROM OUTLETS
UNLESS OTHERWISE NOTED

BLACK = HOT TO PANEL
WHITE = NEUTRAL TO NEUTRAL BUS
GREEN = GROUNDING TO GROUNDING BUS

THIS BOAT IS WIRED FOR 120 VOLT AC, SINGLE PHASE
60 HZ 30 AMP SHOREPOWER SERVICE

FIGURE 8




FIGURE 9

ALL BONDING CONDUCTORS CONNECTED
TO ENGINE NEGATIVE BUS

BONDING (DC GROUNDING) ISLAND PACKET 440

HULLS #01 THRU 04

FRESH WATER SYSTEM ISLAND PACKET 440

HULLS 1 TO 32




FIGURE 10

FRESH WATER SYSTEM ISLAND PACKET 440 HULLS 33 AND UP





FIGURE 10



HULLS #05 & UP




FIGURE 12

SANITATION PLUMBING ISLAND PACKET 440




FIGURE 13

FUEL SYSTEM ISLAND PACKET 440

ENGINE BLEEDING PROCEDURE

1. Turn ignition to "on" position.
2. Turn electric fuel pump switch (located inside galley engine room access door) "on" for a few minutes, then turn it off.
3. The above procedures are sufficient for bleeding after servicing fuel filter. If engine is run dry, continue with the following steps:
4. Push in shift disconnect and advance throttle $\frac{1}{4}$.
5. Loosen fuel injector line nuts at injectors. Using the starter, crank engine over and watch for fuel to appear at the top of the injectors. As soon as clear fuel appears, tighten nut. The engine should be kept turning through this whole operation. As you close the injector lines, the engine will start to run. After this procedure, wipe up any fuel around injectors and run engine for a brief period and check for leaks.





FIGURE 14

PROCEDURE TO START ENGINE WITH A DEAD ENGINE START BATTERY:


1. DEPRESS BATTERY PARALLEL SWITCH ON ENGINE PANEL TO PARALLEL ENGINE AND HOUSE BATTERIES.
2. WHILE DEPRESSING BATTERY PARALLEL SWITCH, TURN KEY AS NORMAL TO START ENGINE
3. RELEASE BATTERY PARALLEL SWITCH TO UNPARALLEL ENGINE AND HOUSE BATTERIES

EMERGENCY PROCEDURE BYPASS NEUTRAL SAFETY SWITCH:

1. Disconnect 2 red wires from 2 white wires.
2. Connect white wire to white wire.



NOTE: NOT ALL WIRE CONNECTIONS ARE SHOWN.



**EMERGENCY STARTING
ISLAND PACKET 440**

FIGURE 15